

# Advance PREMIUM

## SET-UP INSTRUCTIONS



1

Open the frame to its full upright position and allow the magnetic frame connectors to connect.



2



Put the channel bars in place on the frame. There are 3 channel bars on each side of the back of the frame, for the end panels.

3

Attach the panels by hooking the top stiffeners to the plastic pegs across the top of the frame.



Once the top is attached, the magnets on either side of the panels will attach to the magnetic strips that run down the length of the channel bars.



(End panels should look like this once properly attached.)

Attach the podium kit by wrapping the fabric panel around the case and attaching the velcro in the back.



4

(Shown with optional Hardwood podium top.)

5

Slide the light into the light foot.



6

Place the light on the outside of the X, on any of the top quads.



Lower the light down slowly until the grooves on the foot line up with the bars.